

AIRPORT CODE		ARRIVALS				DEPARTURES				TOTAL			
<u>VKO</u>													
-- Time Interval		120 min	Hourly			120 min	Hourly			120 min	Hourly	10 min	
Constraint --													
Runway Movements			27				27				27	5	
- MAX Passenger Flow/ Terminal movements.*		X	X			X	X			X	X		
Terminal Indicator -													
International (Terminal B)	pax	1700	850			2000	1200			3700	2000		
	movements	12	6			9	6			21	12		
Domestic (Terminal D)	pax	4800	2400			4800	2400			9600	4800		
	movements	18	9			18	9			28	14		
All Terminals Total	pax	6500	3250			6800	3600			13300	6800		
	movements	30	15			27	15			49	26		
Number of Interval Checks per Hour		24	12			24	12			24	12	2	
Apron Capacity		B		D						Remote	Cargo		
777/A4F										2	2		
747/A330/A340/IL9/M11										7	5		
IL-76										9	4		
757/767/A300/A310/ILW/T20		6								23			
707/727/737/A320/M82/M80/TU5/TU3/YK2/ANF/ AN7/A40/EM2/AT4/S20/CCX/CRJ/GRM										8			
All Other										0			

* For each controlled Terminal, specify its Terminal Indicator (SSIM Appendix D) in the first column.

NOTE:

Except for the apron capacity section (see below), complete only those columns (time intervals) and rows (constraints) which are applicable. For example, if constraints are checked only hourly, then complete only one column for Arrivals and one for Departures (if applicable) and one for Totals. Similarly, if only total Terminal flow is controlled, omit the rows for separate Terminals, International and Domestic Totals, and complete only the "All Terminals Total" row.